

ASSEMBLY INSTRUCTIONS

1. Attach the steel sides to the steps ensuring that the undersides of the steel sections are flush with the bottom of the steps and that the extended flat step at the top sticks out. (This will then fit into the guide slot under the walkway.) Note that the panels without the vertical angle iron edge are at the top of the steps.
2. Attach the long steel section and the steel end sections to the walkway.
3. Attach the step assemblies to each end of the walkway and add the middle steel section between the steps.
4. Assemble two tall and two short steel support towers and attach under the walkway and steps.

All normal polystyrene cements are suitable for assembling this kit.

MADE IN THE UK