

ASSEMBLY INSTRUCTIONS

1. Assemble the back and two side walls.
Add the front top strip, with the lip at the bottom and making sure that it is square (It may help to use the edge of a table as a guide).
2. Glue the windows and door into the brick walls and assemble them. Afix them to the rest of the building using the lips inside the corrugated section as a guide.
3. Add the two roof pieces.
4. On our prototype, the bands on the side walls, the roof ridges and the back wall were dark turquoise, the roller door was silver and the remaining corrugated panels were light grey.

All normal polystyrene cements are suitable for assembling this kit.

MADE IN THE UK